## POLYMER COMPETENCE CENTER LEOBEN GMBH

# Measurement of the water vapour transmission rate of high barrier films at service relevant conditions

#### M. Knausz<sup>1</sup>, G. Oreski<sup>1</sup>, K. Berger<sup>2</sup>, G. Eder<sup>3</sup>, Y. Voronko<sup>3</sup>

<sup>1</sup>Polymer Competence Center Leoben (PCCL), Roseggerstraße 12, 8700 Leoben, Austria – marlene.knausz@pccl.at <sup>2</sup>Austrian Institute of Technology (AIT), Vienna, Austria <sup>3</sup>OFI Austrian Research Institute for Chemistry and Technology, Vienna, Austria



### **Polymer Competence Center Leoben**


### Introduction

- The ingress of water vapour correlates with failure rates in PV modules especially in OPV and thin-film modules
  - Therefore water vapour transmission rates (WVTR) Of 10<sup>-4</sup> to 10<sup>-6</sup> g/m<sup>2</sup>day for encapsulating films should be achieved
- Commercial available test devices are not able to measure such low WVTR and non-commercial available test methods having drawbacks
  - Consequently there is a high demand for an advanced measurement technique for high barrier films

## Objective & methodology

Adaption of a measurement technique for detection of the WVTR in an extended range of  $10^{-6}$  to  $10^{3}$  g/m<sup>2</sup>day at temperatures from 20 to 100°C.

#### Methodology



WEL

# Assembly

Gascell-attachement with heating jacket Enables detection of gas mixtures Due to the lengthening of the IR-beam $\rightarrow$ low detection limit 125ppm (calculated detection time for a film in equilibrium with a WVTR of  $10^{-6}g/m^2day = < 3days$ ) Heating jacket  $\rightarrow$  temperatures up to 100°C possible

Cover

- Desiccant inside  $\rightarrow$ reduces humidity of surrounding

Common FTIR-spectrometer

Purging box Nitrogen purging of valves + pump Climatic chamber

- Temperature range 20 to 100°C
- Relative humidity range 10 to 98%




Permeation cell

- Enlarged permeation area $\rightarrow$ lowered detection time
- Permeation area open to

#### Enables detection of water vapour

#### climatic chamber



- For every point- average of 10 measurement points were taken into

The WVTR test device was concepted and assembled

Conclusion

- The perfect linear fit of the calibration curve at high concentrations proved the suitability
- Further optimisation of the leak tightness as well as the calibration for measurements at low concentrations has to be done



This research work was performed at the Polymer Competence Center Leoben (PCCL) within the project "Analysis of PV Aging" (FFG Nr. 829918, 4. Call "Neue Energien 2020", Klima- und Energiefonds) in cooperation with the Chair of Materials Science and Testing of Plastics at the University of Leoben. The PCCL is funded by the Austrian Government and the State Governments of Styria and Upper Austria.

